



OKIOCAM S-G4K

Quick Start Guide




To download OKIOCAM software, visit:
www.okiolabs.com/download




If you have any questions, please visit:
support.okiolabs.com

Know Your OKIOCAM S-G4K



Buttons



Exposure

Cycles through exposure (brightness) levels (range: -6 to +6)

Zoom

Lossless Sensor Zoom is optimized to provide the best user experience with OKIOCAM Live.

Auto adjust

Adjusts focus, exposure, and white balance automatically.

Mode


Switch between camera modes.

Doc Cam Mode:	Webcam Mode:
Default image orientation. Single auto focus (AFS).	Flipped image orientation. Continuous auto focus (AFC).

Setup


Step 1

Remove the camera and all components from the packaging.




Step 2

Uncoil and straighten the flexible gooseneck arm to its full length.




Step 3

Screw the gooseneck arm into the weighted metal base.




Step 4

Adjust the gooseneck to your desired angle.



Step 5

Connect your OKIOLAB to your computer.



Step 6

Download, install, and launch OKIOLAB Live.
Download it at:
www.okiolabs.com/software/okiocam-live

