OKIOLABS AIO

4K Al Auto Framing Webcam Quick Start Guide



Feb. 2022





We greatly appreciate you putting your trust in us at OKIOLABS! This quick start guide will walk you through the steps to properly set up your OKIOLABS A10, show you how to download and use our software, and how to use your OKIOLABS A10 with third-party apps.

For more information about the OKIOLABS A10, please visit: www.okiolabs/support/A10

Be sure to follow us on all of our social media.

- Twitter
- Facebook
- Instagram
- LinkedIn

The OKIOLABS Team

Table of Contents


OKI	OLABS A10 Overview	2
Set	ting-Up	3
AI A	Auto Framing Function	4
Con	necting to Computer	5
OKI	OCAM Snapshot and Recorder	б
OKIOLABS A10 and Third-Party Applications8		
	Google Meet ·····	8
	Microsoft Teams ·····	8
	Zoom ·····	
	Skype	9



OKIOLABS A10 Overview

The OKIOLABS A10 is a plug-and-play webcam. You do not have to download or install any drivers.

In order to use your OKIOLABS A10, you will need to use it with either OKIOCAM software or third-party applications. It is compatible with all major third-party applications including but not limited to Google Meet, Microsoft Teams, and Zoom.






Setting-Up


Option A: With Laptop/Monitor

 Unfold the clip and place the webcam on the top of your monitor or laptop screen.
 Secure the OKIOLABS A10 by adjusting the clip to press against the back of your device.



Option B: With Tripod


- Fold the clip in and mount the webcam onto a tripod with the ¼ inch standard tripod thread. (Tripod is included with the purchase of OKIOLABS A10.)
 - The tripod extends by twisting and pulling on the end of each lea.
 - The unextended tripod has a height of 5.7in/14.5cm.
 - The extended tripod has a height of 8in/20cm.





Al Auto Framing

 The OKIOLABS A10's Auto Framing function brings an in-person experience to your virtual meetings. The AI technology smartly adjusts the frame depending on the location and number of participants in order to keep everyone at the center of the frame and all in one picture.








- The Al Auto Framing feature only supports up to 1920x1080P.
- To turn on the Al Auto Framing Function simply switch the button on the provided USB cable to the "I" input position.
- LED light on the front of the OKIOLABS A10
 - Blue: The Al Auto Framing function is **on**.
 - Green: The Al Auto Framing function is off.
 - No light: The OKIOLABS A10 is off.







Connecting to your Computer

In order to connect your OKIOLABS A10 to your computer, you must allow it access to function.

Windows:

- Setting
- Privacy
- Camera and switch on **Allow access to your camera**.
- Select each application that you want to use your OKIOLABS A10 with.

macOS System:

- Apple menu
- System Preferences
- Security and Privacy
- Camera from the left side of the screen
- Select the applications that you would like to give camera access to by checking the respective box.

Chromebook Camera:


- Open the native camera app.
- Click the button in the lower-left corner.



OKIOCAM Snapshot and Recorder

You can download OKIOCAM Snapshot and Recorder at www.okiolabs.com/download.

You can use Snapshot and Recorder to take snapshots and record videos with your OKIOLABS A10.



Dashboard

- Click the icon to take a snapshot.
- Click the

 icon to start recording a video.
- Click the icon to pause the recording.
- Click the () icon to stop the video recording.
- Click the icon to mirror your image.
- Zoom Slider:

The top slider on the left side of the screen allows you to zoom up to 6.0x the normal view.



- Click the image.
- Click the * icon to freeze the camera feed.
- Click the icon to reset the camera.
- Click the icon to access the photo and video gallery.




To open the **Settings**, click the icon at the top right side of the screen.


General Settings


- Choose your desired camera, from the **Camera** dropdown menu.
- Choose your desired resolution for photos from the Resolution dropdown menu.
- The **Focus Sound** feature is not applicable for the OKIOLABS A10.
- Choose where your images and videos are saved by clicking
 Change beside Library Folder.
- Choose your desired language from the Language dropdown menu.

Video Recording Settings

- Choose between two different recording aspect ratios from the Aspect Ratio dropdown menu. (4:3 and 16:9)
- Choose your desired video recording resolution from the Quality dropdown menu.
 - -When recording a video with a 4:3 aspect ratio your resolution options are 1024x768 and 1600x1200.
 - -When recording a video with a 16:9 aspect ratio your resolution options are 1280x720 and 1920x1080.
- Choose the microphone that you want to record the audio with from the **Recording Mic** dropdown menu.
- Adjust the microphone volume with the slider labeled Mic Volume.
- Set the **Display when recording** setting to the on position
 () if you want to have the ability to adjust the
 microphone volume directly from within the Live View
 when recording, and set it to the off position () if you
 do not.
- Assign a shutter timer time of either 0, 2, or 5 seconds using the Shutter Timer drop-down menu.
- If Post-Shot Review is set to Yes, after you take a snapshot you will be taken directly to Review Mode.
 If it is set to No, you will not be.









A10 + third-party software

Google Meet

Video

- Click the **More Options** icon at the bottom of the screen.
- Settings
- Video
- Select **OKIOLABS A10** from the **Camera** dropdown menu.

Audio

- Click the **More Options** icon at the bottom of the screen.
- Settings
- Audio
- Select **OKIOLABS A10** from the **Microphone** dropdown menu.

Microsoft Teams

Video

- Click the **More Actions** icon at the bottom of the screen.
- Show device settings
- Select **OKIOLABS A10** from the **Camera** dropdown menu.

Audio

- Click the **More Actions** icon at the bottom of the screen.
- Show device settings
- Select **OKIOLABS A10** from the **Microphone** dropdown menu.

Zoom

Video

- In the bottom left corner click **the arrow** next to Stop Video.
- Select the **OKIOLABS A10** from the list of available cameras.

Audio

- In the bottom left corner click **the arrow** next to Mute.
- Select the **OKIOLABS A10** from the list of available microphones.



Skype

Video

- Click the **More** icon at the bottom right corner of the screen.
- Audio and video settings
- Select **OKIOLABS A10** from the dropdown **Camera** menu.

Audio

- Click the **More** icon at the bottom right corner of the screen.
- Audio and video settings
- Select **OKIOLABS A10** from the dropdown **Microphone** menu.

Slack

Video

- In the top left corner select Settings.
- Select **OKIOLABS A10** from the **Camera** dropdown menu.

Audio

- In the top left corner select **Settings**.
- Select **OKIOLABS A10** from the **Microphone** dropdown menu.



Questions, Comments, Concerns

Once again, thank you for choosing OKIOLABS. We love to hear from our customers, so don't hesitate to reach out and leave us feedback on our product!

If you encounter any technical problems or need additional assistance, please visit: https://support.okiolabs.com

To look at more of our products, services, or blog posts, please visit: www.okiolabs.com

Be sure to follow us on all of our social media.

- Twitter
- Facebook
- Instagram
- LinkedIn